




Capacitive Touch Pad
Owner's Manual



Initial Power up delay: 10 seconds




Preferred Activation Method:




Touch Pad Active / Inactive Table


Rear Window Status	Vehicle Lock Status	Touch Pad Status
		A X
		AX
		A X

Quick Guide: Unlock & Open







Quick Guide: Close & Lock









External Manual Release:




Internal Manual Release:



Capacitive Touch Pad Override: Disable




Capacitive Touch Pad Override: Enable




Compatibility:

Border Control:




Gloves




Compatibility:


Ice & Snow:







Compatibility:



Immunity: The Capacitive Touch Pad has been configured to ignore un-intended triggers when exposed to the following conditions: Carwash, Direct Hose, Dripping Water, Wind, Dust, etc. however the immunity of the Touch Pad cannot be guaranteed in all user cases.

If the user wants to ensure the Capacitive Touch Pad remains inactive in all conditions then the user may lock the base program vehicle &/or deactivate the Capacitive Touch Pad by following the "disable function" instruction in this booklet.

